Service Schematics

Introduction

Important:

This document is intended for use by authorized service centers only.

"Service Schematics" was created with focus on customer care.

The purpose of this document is to provide further technical repair information for NOKIA mobile phones on Level 3/4 service activities.

It contains additional information such as e.g. "Component finder".

Saving process time and improving the repair quality is the aim of this document. It is to be used additionaly to the service manual and other training or service information such as Service Bulletins.

While every endeavour has been made to ensure the accuracy of this document, some errors may exist. If the reader finds any errors, NOKIA should be notified in writing.

Please send E-Mail to: <u>TrainingAndVendor.Development@nokia.com</u>




RM-242





Table of contents	
Frontpage	1
Sytem connector	2
AVILMA & BETTY	3
RAP3GS, microSD card & microphne	4
FM & BT module	5
Camera interface & HW accelerator	6
B2B connector & User interface	7
Camera & bottom flex	8
Top flex & top board	9
RF part	10
Component finder	11


Copyright © NOKIA


This material, including documentation and any related computer programs is protected by copyright, controlled by NOKIA. All rights are reserved. Copying, including reproducing, modifying, storing, adapting or translating any or all of this material requires the prior written consent of NOKIA. This material also contains confidential information, which may not be disclosed to others whitout the prior written consent of NOKIA.














Camera Flex 2AMG_04

